



EXCEL MODULAR LADDER CAGE

Part Number	Description	Weight (lbs.)
LC	Ladder Cage Hoop	10
SLC	Snow Ladder Cage Hoop	12
LC3/4-L	Ladder Cage 3/4 Hoop Left	9
LC3/4-R	Ladder Cage 3/4 Hoop Right	9
SLC3/4-L	Snow Ladder Cage 3/4 Hoop Left	11
SLC3/4-R	Snow Ladder Cage 3/4 Hoop Right	11
LCB4	Ladder Cage Brace 4'	3.5
LCB2	Ladder Cage Brace 2'	1.8



Excel Modular ladder cage accessories allow ladder cages to be added to most scaffold ladders.

BUILD NOTES:

1. The ladder cage should always be removed starting from the bottom towards the top to prevent the swinging of brace components while being dismantled.
2. Ladder cage 3/4 hoops are used to create an opening in the ladder cage to exit to different deck elevations.
3. Tube and clamp is used to provide a handrail at the opening and can be adjusted to fit any scaffold design.
4. Any combination of horizontals/tube and clamp can be used for the handrail.
5. The installer should ensure the cage extends down the ladder to a point not less than seven (7) feet and no more than eight (8) feet above the base of the ladder. It should also extend a minimum of 42 inches above the top of the landing, unless other acceptable protection is provided.

All material must be inspected prior to use! See inspection guidelines on page 43 of this manual.