


EXCEL MODULAR ROOF ADAPTER

	Part Number	Description	Weight (lbs.)	Maximum Allowable Load (ft. lbs.)
	RA	Roof Adapter	5.8	1,000



All material must be inspected prior to use! See inspection guidelines on page 43 of this manual.



Support must be added at point "A" or "B" to prevent the verticals from spreading apart.

The roof adapter is a leg connector which can be used to create a temporary shelter by adding a tarp over the top.

BUILD NOTES:

- 1. When covering scaffold with plastic, tarps or other types of solid material, the user must consider all wind and or snow loading.
- 2. An Excel Engineer should be consulted to ensure proper bracing for the maximum expected wind or snow loads.

CAUTION: There is a pinch point where the two pieces pivot.

Workers should not pass vertical legs with the roof adapters installed. They should be passed separately.